Crushing room CO 25

AFTER WORK:

1) Close valves and switch off ventilation.

2) clean mills:
   - no water on chromium steel!
     Use acetone.
   - clean Backenbrecher (jaw breaker ☺)
     and vertical mill
     with wire brush and pressurized air
   - put materials back into drawers

3) Wipe or vacuum floor, then mop it wet
   Clean tables and sink. After work with vertical mill,
   ideally let the dust settle for ½ day, then clean.

4) cover instruments with supplied sheets

5) empty trash bin if over ½ full
   (into containers on E-floor, in closets in either staircase)

6) report damages and replace consumables

7) enter completion of work in lab journal in E 18,
   it can be found 1 m after door on the right, on map cabinet

8) return room key to lab assistant
   (Chiara Boschi E 18)
   return vertical mill key to FT lab

V.Dietrich/D.Seward/Assistants